

patron

E6 & E9 PLUG INSTALLATION GUIDE

1. Wrap a piece of black electrical tape around the heater's white wire to signify that it is "hot" (along with the black wire).
2. Connect both "hot" wires (black & white) to the two "hot" blades (labelled below).
3. Connect the green wire to the "ground" blade (labelled below).
4. Leave the "Neutral" blade disconnected and remove it from the plug. Final product should look like the image below, but without a neutral blade.

GROUND

HOT

NEUTRAL

Do not insert / remove from plug

