



LAWN & GARDEN

MODEL N° 6413

***OWNER'S MANUAL***

Copy

Keep this Product ID Number and use when contacting Customer Service:

## **IMPORTANT! PLEASE READ BEFORE BEGINNING ASSEMBLY**

Dear Valued Customer,

We would like to congratulate you on your purchase of a Lifetime® Outdoor Storage Shed! We are confident that you have made the perfect choice and you will be very pleased with your new storage solution.

Lifetime® Outdoor Storage is part of the family of products created and manufactured by Lifetime® Products, Inc. Like all of our products, you can be assured that the quality of your Lifetime Outdoor Storage Shed is the best in the world! And, we back that quality up by offering the best warranty in the business – A 10-year warranty that fully covers the Shed!

All of our Sheds are built with the highest-quality steel and high-density polyethylene (HDPE) parts. The design and construction of our steel-reinforced double-Wall Panels is second to none. All of our exposed steel parts and gables are powder coated and we use high-density polyethylene plastic. What makes polyethylene so special? It has superior strength and durability, and, it won't crack or degrade outdoors.

So now that you know the quality you are getting in a Lifetime Outdoor Storage Shed, please take the time to READ THIS INSTRUCTION MANUAL!

We have taken great care in providing the best possible form of instructions to help you put your new Outdoor Storage Shed together. Before you get started, PLEASE read the following preparation tips to help you get started!

We can assure you, your construction experience will be a lot more enjoyable if you do!

### **PREPARATION TIPS:**

- The first step is simple... RELAX! You have made a great purchase, but Rome was not built in a day. Plan to spend a good part of your weekend putting together your fine Outdoor Storage Shed. Our philosophy is, if it comes together quickly and easily, it surely will come apart quickly and easily! Your Lifetime® Outdoor Storage Shed will surely last a long, long time, if you are patient, and take all the time necessary to put it together as we have instructed.
- Grab a friend to join in on the fun! This is not a one-person endeavor. We have found that not only will things go smoother if you have two or more people participating in the construction of the Shed, but it will go quicker as well. So, the more the merrier!
- Make sure you have all the tools necessary for constructing your new Shed. There is a "Tools Required For This Assembly" list on page five of this Owner's Manual.
- The plastic pieces of your Shed may become damaged by over tightening the screws. To avoid this damage, we strongly recommend the use of a low-powered power screwdriver or a drill that has an adjustable clutch that is set on a low-torque setting. If neither is available, use a hand screwdriver. If a hand screwdriver is all you have, take several breaks... your wrist will need it!
- You will also need two small ladders (when it comes time to do the roof!).

## **IMPORTANT! PLEASE READ BEFORE BEGINNING ASSEMBLY**

- Before beginning assembly, remove the Parts List from the center of this Owner's Manual and take an inventory of the parts included with your Outdoor Storage Shed. Also, read through the entire instruction manual. It's always a great practice to get a feel for the flow of the process and to familiarize yourself with the parts involved. But, try not to get ahead of yourself and start the process out of order.
- **FOLLOW THE INSTRUCTIONS IN ORDER!** Everything goes together in a certain order, and we have learned what that correct order should be. In our state-of-the-art research and testing facility, we have painstakingly created these instructions. The order of construction is there for a reason, and some parts simply will not fit if built out of order. Just follow along with the order in the instructions and everything will fit together and things will go very smooth.
- **YOUR SHED MUST BE BUILT ON A LEVEL SURFACE!** If the spot you have chosen to place your wonderful new Outdoor Storage Shed is not level, the Shed will not assemble correctly! We recommend a concrete patio, a wood platform or creating a pad with pea gravel. Your Shed is meant to last a lifetime, so provide the proper foundation for it before you start to build.
- Before you build it, make sure you are allowed to build it! Consult all building codes, as well as city and county ordinances, to ensure that you do not require a building permit to construct your Outdoor Storage Shed. Proper building permit documentation may be required in your neighborhood, and it would be quite unfortunate to learn this after your Outdoor Storage Shed is already built!

Now that you're ready to begin the construction of your wonderful new Outdoor Storage Shed, step back, take a deep breath, get yourself a large cold beverage and enjoy yourself. We guarantee that after spending the right amount of time in building your Shed, you will be able to enjoy it for years to come.

Thanks for choosing Lifetime®, and have fun!

## **ABOUT LIFETIME PRODUCTS, INC.**

Lifetime Products, Inc., has applied innovation and cutting-edge technology in plastics and metals to create a family of affordable lifestyle products that feature superior strength and durability. The world's leading manufacturer of folding tables and chairs, Lifetime was founded in 1986 as the maker of portable basketball systems that revolutionized the industry with patented technology. With diverse offerings such as outdoor storage sheds and steel utility trailers, Lifetime continues to develop innovative products that outfit the way you live.

Lifetime makes the things you need for the lifestyle you want. By innovating products in and around the home, Lifetime simplifies your everyday life and enables you to get the most out of your free time.



## REGISTER YOUR LIFETIME PRODUCT TODAY!

There are benefits to registering your Lifetime product. With our new online product registration form, it's fast and easy! Register with us at [www.lifetime.com](http://www.lifetime.com) and enjoy these great benefits:

- Receive exclusive money-saving offers from BuyLifetime.com, our online store, as well as NEW product notifications and special closeout promotions!
- In the unlikely event of a product recall or safety modification, we will notify you.
- Registering your product guarantees you warranty service. If you do not register your product, your warranty rights will not be diminished. But you will need to provide a sales receipt to verify your product purchase date before warranty service will be provided.

### LIFETIME'S PROMISE TO YOU:

*Maintaining your privacy is our long-standing policy at Lifetime. And you can rest assured that Lifetime will not sell or provide your personal data to other third parties, or allow them to use your personal data for their own purposes.*

We invite you to read our privacy policy at [www.lifetime.com](http://www.lifetime.com)

**REGISTER today!**

**\*\*U.S. and Canada customers ONLY\*\***

IF ASSISTANCE IS NEEDED,

**DO NOT CONTACT THE STORE!**

**CALL OUR CUSTOMER SERVICE DEPARTMENT at 1 (800) 225-3865**

HOURS: 7:00 a.m. to 5:00 p.m. Monday through Friday (Mountain Standard Time)

\*\*Call, or visit our Web site for Saturday hours\*\*

\*\*For customers outside the U.S. or Canada, please contact the store for assistance.\*\*



## SAFETY INSTRUCTIONS



### FAILURE TO FOLLOW THESE WARNINGS MAY RESULT IN SERIOUS INJURY OR PROPERTY DAMAGE AND WILL VOID WARRANTY.

To ensure safety, do not attempt to assemble this product without following the instructions carefully. Check entire box and inside all packing material for parts and/or additional instruction material. Before beginning assembly, read the instructions and identify parts using the hardware identifier and parts list in this document. Proper and complete assembly, use and supervision are essential to reduce the risk of accident or injury.

- Do not use or store hot objects such as grills, blowtorches, welding equipment, etc. near the product.
- If using a ladder during assembly, use extreme caution.
- Two capable adults are required for assembly. (It is also recommended that a third adult function as an instruction reader.)

*Most injuries are caused by misuse and/or not following instructions. Use caution when using this product.*




## BEFORE BEGINNING ASSEMBLY



Keep the hardware bags and their contents separate. If any parts are missing, call our Customer Service Department.



Read the "Congratulations" letter on page 2-3. Identify and inventory all parts and hardware using the parts and hardware lists and identifiers in this document.



***\*Two adults required to complete assembly\****

**Only adults should set up the product. Do not allow children in the set-up area until assembly is complete.**



## TOOLS REQUIRED FOR ASSEMBLY

7/16"

3/8"

Adjustable

Hammer

Rubber Mallet


Box Knife

Phillips  
Screwdriver

Plain Screwdriver

3/8" Masonry Bit

2" x 4" x 3'  
Leveling Board



(2)

(1)

(1)

(1)

(1)

(1)

(1)

(1)

(1)

(1)

(1)

6' Ladder

Power Drill\*



Work Light

Pliers

Flashlight

Hammer Drill\*

Safety Glasses



(2)

(1)

(1)

(1)

(1)

(1)

(1 for each person)

\*See "Screwdriver Notice" on page 7.

## ASSEMBLY GUIDES

*Refer to the following areas throughout the instructions to assist in the assembly process:*

This area is located at the top, left-hand corner of the page and indicates which tools and hardware are needed to complete the assembly steps on a page.



TOOLS AND HARDWARE REQUIRED FOR THIS PAGE

This area is located at the top, right-hand corner of the page and shows an image of the product with shaded parts indicating which section is being assembled.

SEC #

This area is usually located in the bottom, left-hand corner of a step and indicates that special attention is needed to perform a particular part of a step.



Note:

These areas are usually located in the bottom, right-hand corner of a step and indicate that damage to the product or serious injury may occur if the caution or warning is not heeded.




**CAUTION**



**WARNING**

Throughout the Parts & Hardware List, Part & Hardware Identifiers, and instructions are three-letter IDs. These IDs are below the images of the parts and hardware to help you locate and identify the parts and hardware during assembly. These IDs are not necessarily on the parts themselves.



ADZ (x10)  
1/4" x 5/8" Pan-Head Screw

## IMPORTANT NOTICES

### Level Surface Notice:

Surface must be leveled before installation. We recommend building a level work space with a concrete or patio style surface. If the surface is not properly leveled, the Outdoor Shed will not assemble correctly. Proper surface leveling will save you time in the long run, so please do not ignore this step.

---

### Building Code Notice:

Consult all local building codes, as well as city and county ordinances, to ensure that the construction of the Outdoor Shed does not require a building permit. Proper building permit documentation may be required in your neighborhood, and it would be unfortunate to learn this after constructing the Shed.

---

### Screwdriver Notice:

You may use a #2 Phillips head screwdriver bit and a power screwdriver or drill, instead of a hand screwdriver. However, be aware that the plastic pieces of your Shed can be damaged by overtightening of screws. To avoid damage we strongly recommend the use of a low-powered power screwdriver or a drill that has an adjustable clutch that is set on a low torque setting. If neither is available, use a hand screwdriver. In any case use caution to avoid overtightening the screws.

---

### Floor Puncture Notice:

Sharp objects may damage your floor. If resting sharp, heavy objects on your Shed floor, place a block of wood between the sharp object and floor.



### CAUTION:

If more than six (6) inches of snow accumulate on the roof of the shed, carefully remove the snow to avoid possible roof collapse. While standing on the ground, remove the snow from the roof with a broom or snow shovel. Do not stand on the roof to remove snow.


## PARTS LIST

ID	Description	Qty	ID	Description	Qty
<b>SHED PARTS BOX</b>			<b>BEF LEFT DOOR ASSEMBLY HARDWARE</b>		
AGZ	Right Door	1	AHZ	Left Door Handle	1
AGO	Left Door	1	AHM	Deadbolt Latch	2
AGF	Entry Gable	1	ABU	1/4" x 1 1/2" Carriage Bolt	2
AGH	Rear Gable 1	1	ADW	#10 x 3/4" Pan-Head Screw	3
AGI	Rear Gable 2	1	AEE	#10 x 1/2" Flat Washer	3
BLD	Floor Panel	1	ADJ	1/4" Cap Nut	2
AFV	90" Shelf	1	AIA	Left Door Lock Bracket	1
AGQ	Roof Panel	2	AIB	Left Door Strike Plate	1
AGY	Corner Wall Panel 104	1	<b>BEG RIGHT DOOR ASSEMBLY HARDWARE</b>		
AGN	Corner Wall Panel 105	1	AIK	Right Door Handle	1
AGW	Corner Wall Panel 106	1	ABV	1/4" x 2" Carriage Bolt	2
AGL	Corner Wall Panel 107	1	ADB	3/8" x 1/2" Steel Spacer	2
AHD	Wall Panel	2	AAB	1/4" Centerlock Nut	2
AHC	Skylight	1	AHY	Latch Spring	1
AGG	Front Roof Cap	1	AHW	Latch Block	1
AFW	Rear Roof Cap	1	AIO	Thumb Lever	1
AFZ	Corner Shelf	2	ADW	#10 x 3/4" Pan-Head Screw	4
AFS	10" x 30" Shelf	2	AHX	Latch Cover Plate	1
<b>DBL METAL PARTS KIT</b>			AHV	Door Latch	1
AFC	Door End Channel	2	AIL	Right Door Lock Bracket	1
AFM	Shelf Support Channel	2	AEB	1/4" Flat Washer	2
AFE	Entry Header Bar	1	AEE	#10 x 1/2" Flat Washer	5
CRD	Door Hinge Tube	2	<b>BHZ DOOR &amp; FRONT GABLE INSTALLATION HARDWARE</b>		
AFL	Roof Support	2	ADZ	1/4" x 5/8" Pan-Head Screw	6
<b>BHV GABLE ASSEMBLY HARDWARE (x2)</b>			AHP	Cotter Pin	2
AGP	Louvered Vent	1	AIC	Left Gap Flap	1
AIQ	Vent Screen	1	AIM	Right Gap Flap	1
ADW	#10 x 3/4" Pan-Head Screw	5	ADX	#10 x 1/2" Pan-Head Screw	4
AEE	#10 x 1/2" Flat Washer	5	<b>BRY REAR GABLE, ROOF, &amp; TRUSS INSTALLATION HARDWARE</b>		
ADZ	1/4" x 5/8" Pan-Head Screw	4	ADZ	1/4" x 5/8" Pan-Head Screw	48
AHS	End Plug	2	AED	#10-1" Fender Washer	6
ADV	1/4" x 1 1/8" Pan-Head Screw	6	ADX	#10 x 1/2" Pan-Head Screw	22
ACB	#10 x 1 1/8" Pan-Head Screw	1	AXX	Truss Hole Insert	2
<b>BRW SMALL PARTS BOX</b>			<b>BHC PEGBOARD STRIP INSTALLATION HARDWARE</b>		
AIX	Wood Shim	4	ADW	#10 x 3/4" Pan-Head Screws	10
AIW	Wood Block	1	<b>BHD Tool Clip Assortment [1029336]</b>		
AFU	Pegboard Strip	1	AIF	2" Double-Arm Hook	1
<b>BQF FLOOR &amp; WALL ASSEMBLY HARDWARE</b>			AIG	4" Double-Arm Hook	1
ADZ	1/4" x 5/8" Pan-Head Screw	38	AIH	J-Hook	3
AHO	Door Hinge Bushing	2	AIL	L-Hook	3
ADC	#2 Phillips Bit	1	AIJ	Toolholder	2
			<b>SHELF HARDWARE</b>		
			<b>BHH 90" &amp; 30" Long Shelf Installation Hardware (x3)</b>		
			ADZ	1/4" x 5/8" Pan-Head Screw	14
			AIY	Shelf Support Bracket	2
			<b>BLE Corner Shelf Installation Hardware (x2)</b>		
			ADZ	1/4" x 5/8" Pan-Head Screw	4


## PARTS IDENTIFIER

### SHED PARTS BOX


Parts shown at 4% scale




**AGO** (x1)  
Left Door




**AGZ** (x1)  
Right Door




**AGF** (x1)  
Entry Gable




**AGQ** (x2)  
Roof Panel



**AGH** (x1)  
Rear Gable 1



**AGI** (x1)  
Rear Gable 2



**BLD** (x1)  
Floor Panel




**AFV** (x1)  
90" Shelf

**!** *Note: Throughout the Parts & Hardware List, Part & Hardware Identifiers, and instructions are three-letter IDs. These IDs are below the images of the parts and hardware to help you locate and identify the parts and hardware during assembly. These IDs are not necessarily on the parts themselves.*


## PARTS IDENTIFIER

### SHED PARTS BOX


Parts shown at 4% scale




**AGY (x1)**  
Corner Wall Panel 104




**AGN (x1)**  
Corner Wall Panel 105



**AGW (x1)**  
Corner Wall Panel 106



**AGL (x1)**  
Corner Wall Panel 107




**AHD (x2)**  
Wall Panel



**AFS (x2)**  
10" x 30" Shelf




**AGG (x1)**  
Front Roof Cap




**AFW (x1)**  
Rear Roof Cap

Parts shown at 8% scale



**AHC (x1)**  
Skylight




**AFZ (x2)**  
Corner Shelf

## PARTS IDENTIFIER


### METAL PARTS KIT [DBL]

Parts shown at 8% scale




**AFC** (x2)

Door End Channel




**AFE** (x1)

Entry Header Bar



**AFM** (x2)

Shelf Support Channel



**CRD** (x2)

Door Hinge Tube



**AFL** (x2)

Roof Support

### SMALL PARTS BOX [BRW]

Parts are not shown to scale



**AIW** (x1)


Wood Block



**AIX** (x4)

Wood Shim

Parts shown at 15% of actual size




**AFU** (x2)

Pegboard Strip


### FLOOR & WALL ASSEMBLY HARDWARE [BQF]

Hardware shown at actual size



**ADZ** (x38)

1/4" x 5/8" Pan-Head Screw  
(Not all screws will be used)



**AHO** (x2)

Door Hinge Bushing



**ADC** (x1)


#2 Phillips Bit




## HARDWARE IDENTIFIER

### GABLE ASSEMBLY HARDWARE [BHV] x2

Parts shown at 8% scale




**AGP** (x1)  
Louvered Vent



**AIQ** (x1)  
Vent Screen


Hardware shown at actual size




**ADZ** (x4)  
1/4" x 5/8" Pan-Head Screw  
(Only 4 used)




**AHS** (x2)  
End Plug  
(Only 2 used)




**AEE** (x5)  
#10 x 1/2" Flat Washer



**ADV** (x6)  
1/4" x 1 1/8" Pan-Head Screw  
(Only 6 used)



**ADW** (x5)  
#10 x 3/4" Pan-Head Screw



**ACB** (x1)  
#10 x 1 1/8" Pan-Head Screw  
(Not used in this model)

### LEFT DOOR ASSEMBLY HARDWARE [BEF]

Part shown at 15% scale

Parts shown at 25% scale




**AHZ** (x1)  
Left Door Handle



**AHM** (x2)  
Deadbolt Latch



**AIA** (x1)  
Left Door Lock Bracket




**AIB** (x1)  
Left Door Strike Plate

Hardware shown at actual size




**ADJ** (x2)  
1/4" Cap Nut



**ABU** (x2)  
1/4" x 1 1/2" Carriage Bolt




**ADW** (x3)  
#10 x 3/4" Pan-Head Screw




**AEE** (x3)  
#10 x 1/2" Flat Washer

### REAR GABLE, ROOF, & TRUSS INSTALLATION HARDWARE [BRY]


Hardware shown at actual size (\*unless otherwise noted)




**ADZ** (x48)  
1/4" x 5/8" Pan-Head Screw  
(Not all screws will be used)



**ADX** (x22)  
#10 x 1/2" Pan-Head Screw



**AED** (x6)  
#10 x 1" Fender Washer




**\*AXX** (x2)  
Truss Hole Insert

## HARDWARE IDENTIFIER

### RIGHT DOOR ASSEMBLY HARDWARE [BEG]


Part shown at 15% scale : Parts shown at 25% scale




**AIK** (x1)  
Right Door Handle




**AHX** (x1)  
Latch Cover Plate



**AIL** (x1)  
Right Door Lock Bracket




**AIO** (x1)  
Thumb Lever




**AHV** (x1)  
Door Latch


Hardware shown at actual size




**ADW** (x4)  
#10 x 3/4" Pan-Head Screw




**AEE** (x5)  
#10 x 1/2" Flat Washer  
(Only 3 used)




**ADB** (x2)  
3/8" x 1/2" Steel Spacer



**AEB** (x2)  
1/4" Flat Washer




**AAB** (x2)  
1/4" Centerlock Nut




**AHY** (x1)  
Latch Spring

Part shown at 50% scale




**AHW** (x1)  
Latch Block




**ABV** (x2)  
1/4" x 2" Carriage Bolt

### DOOR & FRONT GABLE INSTALLATION HARDWARE [BHZ]


Hardware shown at actual size (\*unless otherwise noted)



**ADZ** (x6)  
1/4" x 5/8" Pan-Head Screw




**\*AIC** (x1)  
Left Gap Flap



**\*AIM** (x1)  
Right Gap Flap



**AHP** (x2)  
Cotter Pin




**ADX** (x4)  
#10 x 1/2" Pan-Head Screw

## HARDWARE IDENTIFIER

### SHELF INSTALLATION HARDWARE

#### 90" & 30" Long Shelf Installation Hardware [BHH] (x3)

Hardware shown at actual size



**ADZ** (x14)  
1/4" x 5/8" Pan-Head Screw


Part shown 15% scale



**AIY** (x2)  
Shelf Support Bracket

#### Corner Shelf Hardware [BLE] (x2)


Hardware shown at actual size



**ADZ** (x4)  
1/4" x 5/8" Pan-Head Screw

### PEGBOARD STRIP INSTALLATION HARDWARE [BHC]


Parts shown at actual size




**ADW** (x10)  
#10 x 3/4" Pan-Head Screw

#### Tool Clip Assortment [BHD]


Parts shown at 50% of actual size




**AIF** (x1)  
2" Double-Arm Hook




**AIG** (x1)  
4" Double-Arm Hook



**AIJ** (x2)  
Toolholder



**AIH** (x3)  
J-Hook



**AII** (x3)  
L-Hook



## TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



Concrete (1/3 cu. yd.)

SEC

1



SEC


1.1

### SITE PREPARATION - CONCRETE PLATFORM PREPARATION

The actual dimensions of your shed (at its widest and longest points) are 8' x 2' 6". Ensure you select a site that will accommodate these measurements. The base of the shed is slightly smaller than this, so you will need to create a level surface that is at least 93 1/2" x 28 1/4". We recommend using a level cement or patio style surface. This will provide the best long-term performance for your shed.



**Note:** Shed Extension Kits are available for this shed. Please consider possible shed expansion when planning the site for your shed. See back cover of this manual for information on ordering accessories.



**Note:** Surface must be leveled before installation. If the surface is not properly leveled, the Outdoor Shed will not assemble or function correctly. Proper surface leveling will save you time in the long run, so please do not ignore this step.




**Note:** Any platform or similar structure should be built above ground in order to avoid water pooling inside the Shed.




## TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



2" x 4" x 90 1/2" (x3) (Not included)



2" x 4" x 28 1/4" (x2) (Not included)



16d 3" Common Nail (x12) (Not included)

SEC 1



SEC


1.2

### ALTERNATIVE SITE PREPARATION: OPTION 1 - WOOD PLATFORM ASSEMBLY


Ensure all lumber used is treated and approved for outdoor use. Build outside frame to 93 1/2" x 28 1/4" **outside dimensions**:



*Note: Whenever possible, you should use the surfaces described on Page 7. When this is not possible, we recommend you use a wood platform or a filled wood frame.*



Outside Dimensions



Place the 2" x 4" x 28 1/4" boards on the outside of the frame. Nail each board in place with the 16d nails.



*Note: All lumber must be rated for outdoor use.*



*Note: Surface must be leveled before installation. If the surface is not properly leveled, the Outdoor Shed will not assemble or function correctly. Proper surface leveling will save you time in the long run, so please do not ignore this step.*



## TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



28 1/4" x 93 1/2" x 3/4" Treated Plywood (x1) (Not included)



8d 1 1/2" Common Nail (x22)  
(Not included)

SEC 1




SEC

1.3

### ALTERNATIVE SITE PREPARATION: OPTION 1 - WOOD PLATFORM ASSEMBLY (CONT)

Square up the frame by measuring from corner to corner. Measurement A should equal Measurement B.




*Note: All lumber must be rated for outdoor use.*

SEC

1.4

Cut Plywood to the required size. Arrange the Plywood according to the diagram and nail into place with 8d x 1 1/2" nails. Place platform in the desired location. If platform does not rest level on the ground, build up low points with loose dirt until platform is stable. Drill three evenly spaced 1/2" drain holes in plywood between each 2" x 4" joist.




Drill three evenly spaced 1/2" drain holes in plywood between each 2" x 4" joist.




## TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



2" x 4" x 96" (x2) (Not included)




2" x 6" x 23" (x2) (Not included)



8d 1 1/2" Common Nail (x16)  
(Not included)



Pea Gravel (4.5 Cubic Feet)  
(Not included)



L-Bracket (x4)  
(Not included)

SEC 1



SEC

1.5

### ALTERNATIVE SITE PREPARATION: OPTION 2 - FILLED WOOD FRAME ASSEMBLY



Cut outside frame to 8' x 2'6" outside dimensions. Lay boards flat so widest parts face up. Ensure frame is level. Square up the frame by measuring from corner to corner. Measurement A should equal Measurement B. Nail an L-Bracket on each corner of the frame with 8d nails. Place platform in the desired location. If platform does not rest level on the ground, build up low points with loose dirt or "Pea" gravel, until platform is stable.



*Note: Whenever possible you should use the surfaces described on Page 7.*




*Note: All lumber must be rated for outdoor use.*



SEC

1.6


Once all boards are level and do not wobble, pack "Pea" gravel around the outside of the frame, and slope away from frame.



SEC

1.7

Now fill the inside of the frame with "Pea" gravel. Use a leveling board to scrape off extra fill material and to level the surface.




2" x 4" x 2'6" Leveling Board (x1)




## SEC 2 FLOOR & WALL ASSEMBLY

### HARDWARE REQUIRED

Hardware shown at actual size



**ADZ** (x38)  
1/4" x 5/8" Pan-Head Screw  
(Not all are used)




**AHO** (x2)  
Door Hinge Bushing




**ADC** (x1)  
#2 Phillips Bit

### PLASTIC PARTS REQUIRED


Parts shown at 4% of actual size




**AGY** (x1)  
Corner Wall Panel 104




**AGN** (x1)  
Corner Wall Panel 105




**AGW** (x1)  
Corner Wall Panel 106



**AGL** (x1)  
Corner Wall Panel 107



**BLD** (x1)  
Floor Panel



**AHD** (x2)  
Wall Panel

### TOOLS REQUIRED



Phillips Screwdriver



Safety Glasses



**AIW** (x1) Wood Block (Included)



**ADC** (x1) #2 Phillips Bit (Included)



## TOOLS AND HARDWARE REQUIRED FOR THIS PAGE




AIW (x1)



AHO (x2)

SEC 2




SEC

2.1

### FLOOR ASSEMBLY

Lay the **Floor Panel (BLD)** flat on the ground. Lift the Floor Panel up enough to slide the two (2) **Door Hinge Bushings (AHO)** under and up through the holes in the Floor Panels as shown. **This will be the front of your shed. The door hinges will be inserted in these bushings later in the assembly.**



### CAUTION


Sharp objects may damage your floor. If resting sharp, heavy objects on your shed floor, place a block of wood between the sharp object and floor.

SEC

2.2

### WALL ASSEMBLY

Fold **Corner Wall Panel 105 (AGN)**. Fit tabs of Panel into the front left corner (while facing shed) of your floor. Place the **Wood Block (AIW)** under directly under the first tab of the Floor Panel, then pull down on Corner Panel until tab snaps into place. Move Wood Block under the next tab and repeat.




**Note:** Place Wood Block (AIW) directly under the tab you are inserting. Snap tabs into place one at a time.



## TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



AIW (x1)



ADZ (x5)

SEC



2



SEC

2.3


Fit tabs of the **Corner Wall Panel 107 (AGL)** into the back left corner of your floor.



SEC

2.4

Fasten Corner Panels together using the required hardware.



**!** *Note: Second person should apply pressure on opposite side of the wall for easy insertion of screws.*



## TOOLS AND HARDWARE REQUIRED FOR THIS PAGE




AIW (x1)



ADZ (x15)


SEC 2



SEC

2.5



Snap **Wall Panels (AHD)** into place along the rear side of the Floor Panel, and fasten together using the required hardware.



SEC

2.6

Snap the tabs of the **Corner Wall Panel 106 (AGW)** into position, as shown. Secure the Panels using the required hardware.






## TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



AIW (x1)



ADZ (x5)

SEC


2



SEC

2.7

Fit tabs of the **Corner Wall Panel 104 (AGY)** into position, as shown. Secure the Panels using the required hardware.



AGY




## TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



**IF YOU PLAN ON ANCHORING YOUR SHED, CHECK WITH YOUR LOCAL HARDWARE STORE FOR SUITABLE HARDWARE.**

SEC

2




SEC

2.8

### ANCHORING THE SHED

If you plan on anchoring your shed, you can anchor it to your platform through the four indentations near the corners of the floor. The anchoring hardware used depends on the platform. If you have a concrete platform, we recommend using four (4) 3/8" Anchor Bolts and four (4) 3/8" x 1" Flat Washers. If you have a wood framed platform, we recommend using four (4) 3/8" Lag Bolts and four (4) 3/8" x 1" Flat Washers. Do not exceed a 3/8" diameter bolt. Refer to your local hardware store for this hardware. **Do not tighten anchoring hardware until instructed to do so at the end of these instructions.**



### WARNING


Failure to anchor the shed may result in property damage and/or personal injury.




## SEC 3 LEFT DOOR ASSEMBLY

### HARDWARE REQUIRED

Hardware shown at actual size




**ADW** (x3)  
#10 x 3/4" Pan-Head Screw



**ABU** (x2)  
1/4" x 1 1/2" Carriage Bolt




**ADJ** (x2)  
1/4" Cap Nut



**AEE** (x3)  
#10 Flat Washer

Part shown at 25% of actual size



**AHM** (x2)  
Deadbolt Latch



**AIB** (x1)  
Left Door Strike Plate



**AIA** (x1)  
Left Door Lock Bracket


Part shown at 15% of actual size




**AHZ** (x1)  
Left Door Handle

### METAL PARTS REQUIRED

Part shown at 8% of actual size




**AFC** (x1)  
Door End Channel



**CRD** (x1)  
Door Hinge Tube

### PLASTIC PARTS REQUIRED

Part shown at 4% of actual size



**AGO** (x1)  
Left Door

### TOOLS REQUIRED



Phillips Screwdriver



7/16" Wrench




Safety Glasses





## TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



AHM (x2)




SEC 3

### SEC

#### 3.1

### LEFT DOOR ASSEMBLY


Rest the **Left Shed Door (AGO)** with front side down. Slide a **Door Hinge Tube (CRD)** through the hole in the Door as shown.



### SEC

#### 3.2

Position the **Deadbolt Latches (AHM)** in the slots at the top and bottom of the Door, then slide the **Door End Channel (AFC)** onto the Door as shown.



*Note: The Door End Channel fits onto Door with the flat side up (facing the Deadbolt Latches).*




## TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



7/16"



AIB (x1)



ABU (x2)



ADJ (x2)



AIA (x1)




SEC

3

### SEC

#### 3.3

Slip the **Left Door Strike Plate (AIB)** over the Left Shed Door and align the holes.




*Note: You may need to nudge the Door End Channel to make these holes line up with the gap in the Door.*

### SEC

#### 3.4

Attach the **Left Door Lock Bracket (AIA)** to the Left Door Strike Plate with two **1/4" x 1 1/2" Carriage Bolts (ABU)** and two **1/4" Cap Nuts (ADJ)**.



### WARNING


Do not overtighten the Cap Nut. If the end of the Bolt breaks through the plastic cap, call our Customer Service Department. Exposed threads on the end of the Bolt may cause serious injuries.



## TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



ADW (x3)



AEE (x3)

SEC


3



SEC

3.5


Attach the **Left Door Handle (AHZ)** using three (3) #10 Flat Washers (AEE) and three (3) #10 x 3/4" Pan-Head Screws (ADW).




## SEC 4 RIGHT DOOR ASSEMBLY

### HARDWARE REQUIRED

Hardware shown at actual size




**ABV** (x2)  
1/4" x 2" Carriage Bolt




**AEE** (x5)  
#10 Flat Washer  
(Only 3 are used)




**ADB** (x2)  
3/8" x 1/2" Steel Spacer




**AAB** (x2)  
1/4" Centerlock Nut



**AHY** (x1)  
Latch Spring



**ADW** (x4)  
#10 x 3/4" Pan-Head Screw




**AEB** (x2)  
1/4" Flat Washer


Part shown at 25% of actual size




**AHX** (x1)  
Latch Cover Plate



**AIL** (x1)  
Right Door Lock Bracket




**AHV** (x1)  
Door Latch




**AIO** (x1)  
Thumb Lever

Part shown at 15% of actual size



**AIK** (x1)  
Right Door Handle


Part shown at 50% of actual size



**AHW** (x1)  
Latch Block

### METAL PARTS REQUIRED


Part shown at 8% of actual size



**AFC** (x1)  
Door End Channel




**CRD** (x1)  
Door Hinge Tube



### PLASTIC PARTS REQUIRED

Part shown at 4% of actual size



**AGZ** (x1)  
Right Door

### TOOLS REQUIRED



Phillips Screwdriver



7/16" Wrench



Safety Glasses



## TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



NO HARDWARE REQUIRED FOR THIS PAGE

SEC 4




SEC

4.1

### RIGHT DOOR ASSEMBLY


Rest the **Right Shed Door (AGZ)** with front side down. Slide a **Door Hinge Tube (CRD)** through the hole in the Door as shown.



SEC

4.2

Slide the **Door End Channel (AFC)** onto the Door as shown.






## TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



NO HARDWARE REQUIRED FOR THIS PAGE

SEC


4



SEC

4.3


Fit knobs of **Thumb Lever (A10)** into the grooves of **Right Door Handle (AIK)**.



SEC

4.4


Rotate the Thumb Lever into the Right Door Handle. Slide forward until the knobs fit into the holes in the Handle.









## TOOLS AND HARDWARE REQUIRED FOR THIS PAGE




7/16"




AAB (x2)




ABV (x2)




ADB (x2)



AEB (x2)



ADW (x3)



AEE (x3)


SEC 4



SEC

4.5

Attach the Right Handle Assembly to the Door using three (3) #10 Flat Washers (AEE) and three (3) #10 x 3/4" Pan-Head Screws (ADW).





### CAUTION

Do not overtighten. Overtightening may damage parts and void warranty.

SEC

4.6

Install Handle Latch assembly onto the Right Shed Door using the required hardware.




**Note:** The Door Latch (AHV) goes on top of the Thumb Lever (AIO).







## TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



AHY (x1)




AHW (x1)



ADW (x1)

SEC


4



SEC

4.7

Line up the hole in the **Latch Block (AHW)** with the hole in the Thumb Lever and secure with one (1) **#10 X 3/4" Pan-Head Screw (ADW)**.




*Note: The lip of the Latch Block (AHW) fits under the Thumb Lever (A10).*

SEC

4.8

Attach **Latch Spring (AHY)** to the **Door Latch (AHV)** and the **Latch Cover Plate (AHX)**. Set the Door aside.



*Note: Use pliers to pull spring down and hook into bottom hole.*




### WARNING

While performing this step, each person should use protective eye glasses to help prevent serious eye injury.


## SEC 5 GABLE ASSEMBLY

### HARDWARE REQUIRED


Hardware shown at actual size




**AEE** (x10)  
#10 x 1/2" Flat Washer




**ADW** (x10)  
#10 x 3/4" Pan-Head Screw




**ADZ** (x8)  
1/4" x 5/8" Pan-Head Screw  
(Only 4 used)



**ADV** (x12)  
1/4" x 1 1/8" Pan-Head Screw  
(Only 6 used)




**AHS** (x4)  
End Plug  
(Only 2 used)




**ACB** (x2)  
#10 x 1 1/4" Pan-Head Screw  
(Not used in this model)

Parts shown at 8% of actual size



**AGP** (x2)  
Louvered Vent




**AIQ** (x2)  
Vent Screen

### METAL PARTS REQUIRED

Part shown at 8% of actual size




**AFE** (x1)  
Entry Header Bar



### METAL PARTS KIT REQUIRED: CMT


### PLASTIC PARTS REQUIRED

Parts shown at 4% of actual size




**AGF** (x1)  
Entry Gable

(Rear View)



**AGH** (x1)  
Rear Gable 1

(Rear View)



**AGI** (x1)  
Rear Gable 2

(Rear View)

### TOOLS REQUIRED




Phillips Screwdriver



Safety Glasses



## TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



ADZ (x4)

SEC

5




SEC

5.1

### REAR GABLE ASSEMBLY


Lay the edge of **Rear Gable 2 (AGI)** over **Rear Gable 1 (AGH)** as shown, and align the four holes.



SEC

5.2


Connect Rear Gables 1 & 2 together using four (4) **1/4" x 5/8" Pan-Head Screws (ADZ)** as shown.




*Note: Only use a hand screwdriver in this step.*



## TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



ADW (x5)



AEE (x5)


SEC 5



SEC

5.3


Lay Rear Gable Assembly flat on the ground over the **Vent Screen (AIQ)** and **Louvered Vent (AGP)**. Align the holes in the Louvered Vent with those in the Rear Gable Assembly.



SEC

5.4


After aligning the holes, press down firmly on the Rear Gable Assembly while inserting the five (5) **#10 x 3/4" Pan-Head Screws (ADW)** and the five (5) **#10 x 1/2" Flat Washers (AEE)**. Pressing down firmly while inserting the Screws will help prevent the Vent Screen from twisting. Set aside.




*Note: Only use a hand screwdriver in this step.*



## TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



ADW (x5)



AEE (x5)

SEC

5




SEC

5.5

### ENTRY GABLE ASSEMBLY


Lay **Entry Gable (AGF)** flat on the ground over the **Vent Screen (AIQ)** and **Louvered Vent (AGP)** as shown. Align the holes in the Louvered Vent with those in the Entry Gable.



SEC

5.6

After aligning the holes, press down firmly on the Entry Gable when inserting the five (5) **#10 x 3/4" Pan-Head Screws (ADW)** and the five (5) **#10 x 1/2" Flat Washers (AEE)**. Pressing down firmly while inserting the Screws will help prevent the Vent Screen from twisting.



*Note: Only use a hand screwdriver in this step.*



## TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



AHS (x2)



ADV (x6)

SEC 5




SEC

5.7

Insert an **End Plug (AHS)** into each end of **Entry Header Bar (AFE)**.

The flat screw holes should face away from the Entry Gable.




*Note: Only use a hand screwdriver in this step.*

SEC

5.8

Attach the Entry Header Bar to the Entry Gable Assembly, and secure with six (6) **1/4" x 1 1/8" Pan-Head Screws (ADV)**. Set aside.

The flat screw holes should face away from the Entry Gable.




*Note: Only use a hand screwdriver in this step.*




## SEC 6 DOOR & ENTRY GABLE INSTALLATION

### HARDWARE REQUIRED


Hardware shown at actual size (\*Unless noted otherwise)




**ADZ** (x6)  
1/4" x 5/8" Pan-Head Screw



**ADX** (x4)  
#10 x 1/2" Pan-Head Screw



**\*AIM** (x1)  
Right Gap Flap




**\*AIC** (x1)  
Left Gap Flap



**AHP** (x2)  
Cotter Pin


### PLASTIC PARTS REQUIRED

Parts shown at 4% of actual size




Entry Gable Assembly

Rear View



Left Door Assembly



Right Door Assembly

### TOOLS REQUIRED



Phillips Screwdriver



Pliers



Safety Glasses



## TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



AHP (x2)


SEC 6



### SEC 6.1




#### DOOR INSTALLATION

Align the hole in the bottom of the Hinge of the **Left Door Assembly** with the hole in the Door Hinge Bushing on the Floor of your shed, and insert the Door Hinge Tube into the Door Hinge Bushing.



### SEC 6.2

Insert a **Cotter Pin (AHP)** through the Bushing and Door Hinge. Use a pair of pliers to bend the ends of the Cotter Pins outward. **Repeat these steps for the Right Door Assembly.**



*Note: Ensure that these two holes line up, so that the Cotter Pin (AHP) can be inserted.*




*Note: Use pliers to bend back the ends of the Cotter Pin (AHP).*





## TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



ADZ (x6)

SEC

6




### 2 ADULTS REQUIRED FOR THESE STEPS

SEC

6.3

#### FRONT GABLE INSTALLATION



Slide the two holes in the **Entry Gable Assembly** down over the Door Hinge Tubes as shown.



SEC


6.4

Align the holes in the sides of the Entry Gable Assembly with those in the tops of the Corner Wall Panels and secure with six (6) **1/4" x 5/8" Pan Head Screws (ADZ)** at the locations indicated.







## TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



ADX (x4)




AIM (x1)  
(Not to scale)



AIC (x1)  
(Not to scale)

SEC 6




SEC

6.5

### GAP FLAP INSTALLATION


Attach the **Right & Left Gap Flaps (AIM & AIC)** to the top, right and left corners of the Side Doors as shown. Before completely tightening the **#10 x 1/2" Pan-Head Screws (ADX)**, slide the Gap Flaps up until they cover any gap between the tops of the Doors and the Gable. **These may be adjusted at any time.**




## SEC 7 REAR GABLE, ROOF, & TRUSS INSTALLATION

### HARDWARE REQUIRED


Hardware shown at actual size (\*Unless otherwise noted)




**ADZ** (x48)  
1/4" x 5/8" Pan-Head Screw  
(Not all screws will be used)



**ADX** (x22)  
#10 x 1/2" Pan-Head Screw  
(Only 6 used)



**AED** (x6)  
#10 x 1" Fender Washer



**\*AXX** (x2)  
Truss Hole Insert

### METAL PARTS REQUIRED

Parts shown at 8% of actual size




**AFL** (x2)  
Roof Support

### METAL PARTS KIT REQUIRED: DBL

### PLASTIC PARTS REQUIRED


Parts shown at 4% of actual size

**115**




**AGG** (x1)  
Front Roof Cap

**116**




**AFW** (x1)  
Rear Roof Cap


Part shown at 8% of actual size



**AHC** (x1)  
Skylight



**AGQ** (x2)  
Roof Panel




**Rear Gable Assembly**

### TOOLS REQUIRED



**Phillips Screwdriver**




**Flashlight**



**Safety Glasses**



## TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



ADZ (x14)



AFL (x2)

SEC


7



SEC

7.1


Attach the Rear Gable Assembly to the shed as shown and secure with fourteen (14) **1/4" x 5/8" Pan-Head Screws (ADZ)**.



SEC


7.2

Set a **Roof Panel (AGQ)** and a **Roof Support (AFL)** onto the two Gable Assemblies. The Gables fit into the grooves along the underside of the Roof Panel. The Roof Support fits into the notches on the Gables.





## TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



ADZ (x22)

SEC


7



SEC

7.3

The bottom lip of the Roof Panel fits over the Wall Panel. The tops of the Corner Wall Panels fit into the groove near the bottom of the Roof Panel. After aligning the holes in the Roof Panel with those in the Corner Wall Panels and Gables, secure the Roof Panel to the shed using the required hardware. **Repeat these steps for the second Roof Panel.**



Interior Upward View



## TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



SEC 7




SEC


7.4

### ROOF CAP INSTALLATION

Starting at the front side of your shed, attach the **Front Roof Cap (AGG)** to the Roof Panels and Entry Gable and then attach the **Rear Roof Cap (AFW)** to the Roof Panels, Front Roof Cap, and Rear Gable.



*Note: Use only a hand screwdriver for this step.*




### CAUTION

Only hand tighten screws. Do not overtighten. Overtightening may damage plastic parts and void warranty.

SEC

7.5


Connect the Roof Caps to each other using two (2) **1/4" x 5/8" Pan-Head Screws (ADZ)**.









## TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



**AXX** (x2)  
(Not to scale)



**ADX** (x6)



**AED** (x6)

SEC 7



SEC

7.6


### SKYLIGHT INSTALLATION

Pre-fold **Skylight (AHC)** before installing. Push folded Skylight up through opening between the Roof Caps; open Skylight; use tabs to pull Skylight down into place. Fasten Skylight in place with six (6) **#10 x 1" Fender Washers (AED)** and six (6) **#10 x 1/2" Pan-Head Screws (ADX)** (pull down on tabs while inserting screws to provide resistance).




*Note: Use only a hand screwdriver for this step.*


**AHC**



**AHC**



Pull down on tabs while inserting screws.




SEC


7.7

### GABLE CLIP INSERTION

Insert the **Truss Hole Inserts (AXX)** between the rear Gable and the rear Wall of the Shed as shown.




*Note: Gable Clip can only be inserted with the arrow pointing up.*



## SEC 8 SHELF INSTALLATION

### HARDWARE REQUIRED

Hardware shown at actual size




**ADZ** (x42)  
1/4" x 5/8" Pan-Head Screw  
(Not all are used)

Part shown at 15% of actual size




**AIY** (x6)  
Shelf Support Bracket




**ADZ** (x8)  
1/4" x 5/8" Pan-Head Screw

### METAL PARTS REQUIRED

Part shown at 8% of actual size



**AFM** (x2)  
Shelf Support Channel



### METAL PARTS KIT REQUIRED: CMT

### PLASTIC PARTS REQUIRED

Part shown at 4% of actual size




**AFV** (x1)  
90" Shelf



**AFS** (x2)  
10" x 30" Shelf

Part shown at 8% of actual size



**AFZ** (x2)  
Corner Shelf

### TOOLS REQUIRED



Phillips Screwdriver




Safety Glasses





## TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



ADZ (x8)

SEC

8





### SEC

#### 8.1


### WALL/SHELF SUPPORT CHANNEL INSTALLATION

Insert a **Shelf Support Channel (AFM)** into the slots in the Wall Panels directly below the Right Truss notch, and secure with four (4) **1/4" x 5/8" Pan-Head Screws (ADZ)**. Insert a second Shelf Support Channel in the slot directly to the right of the Left Truss Notch and secure with four (4) **1/4" x 5/8" Pan-Head Screws**.





## TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



ADZ (x6)

SEC 8




SEC

8.2

### 90" SHELF INSTALLATION

Set a **Shelf Support Bracket (AIY)** into the slots of each of the Shelf Support Channels. The slots must be at the same height.




*Note: Insert Shelf Support Bracket at an angle.*


SEC

8.3

Fold up flaps on the end of **90" Shelf (AFV)**. Set Shelf on Brackets with indentations toward wall, and secure with six (6) **1/4" x 5/8" Phillips Pan-Head Screws (ADZ)**.



Upward view



### WARNING


The weight limit for a 90" Shelf is 30 lb. per 30" section of Wall Panel. Failure to heed this warning could result in property damage and/or personal injury.



*Note: There are only holes for screws along front side of the Shelf (front is labeled "Front" on underside of Shelf).*



## TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



ADZ (x8)

SEC

8



SEC


8.4

### 10" x 30" SHELF INSTALLATION

Insert a pair of **10" Shelf Support Brackets (AIY)** into the slots in the Wall/Shelf Support Channels and set a **10" x 30" Shelf (AFS)** on Brackets. Secure with four (4) **1/4" X 5/8" Phillips Pan-Head Screws (ADZ)**. Repeat this step for the second 10" x 30" Shelf.



AIY




### WARNING

The total weight placed on a 10" x 30" Shelf cannot exceed 30 pounds (14kg.) per Wall Panel.



## TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



ADZ (x8)

SEC

8




SEC


8.4

### CORNER SHELF INSTALLATION


Fold up edges of a **Corner Shelf (AFZ)**. Line-up holes in the Corner Shelf with a set of pre-made holes in any Corner Panel as shown. Secure with four (4) **1/4" x 5/8" Phillips Pan-Head Screws (ADZ)**. Repeat this step for the second Corner Shelf.



Holes



ADZ




### WARNING

The total weight placed on a Corner Shelf cannot exceed 10 lb. (4.5 kg).

## SEC 9 PEGBOARD STRIP INSTALLATION

### HARDWARE REQUIRED


Hardware shown at actual size




**ADW** (x10)  
#10" x 3/4" Pan-Head Screw

### HARDWARE BAGS REQUIRED: BHC, BHD


Hardware shown at 50% of actual size




**AIG** (x1)  
4" Double-Arm Hook




**AIJ** (x2)  
Toolholder



**AIF** (x1)  
2" Double-Arm Hook




**AIH** (x3)  
J-Hook



**AIL** (x3)  
L-Hook

### PLASTIC PARTS REQUIRED

Parts shown at 15% of actual size



**AFU** (x2)  
Pegboard Strip

### SMALL PARTS BOX REQUIRED: BRW

### TOOLS REQUIRED



Phillips Screwdriver





Safety Glasses



Level



## TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



ADW (x10)

SEC 9



### SEC


#### 9.1

### PEGBOARD STRIP INSTALLATION

Using a level, position the **Pegboard Strip (AFU)** in any desired location along a Wall Panel wall. Screw the Pegboard Strip to the Wall using five (5) **#10 x 3/4" Phillips Pan-Head Screws (ADW)**. See Note. Repeat this step for second Pegboard Strip.



**Note:** The Pegboard Strip is screwed directly into the plastic. Line up the Strip anywhere on Wall so holes are over plastic (and not over a groove in the Wall).



**Note:** Ensure the Pegboard Strip is level before inserting Screws.

### SEC

#### 9.2

Insert **Hooks (AIF, AIG, AIH, AII, and AIJ)**.


## SEC 10 FINAL STEPS

### *HARDWARE REQUIRED*

NO HARDWARE PROVIDED FOR THIS SECTION

### *TOOLS REQUIRED*

*SMALL PARTS BOX REQUIRED: BRW*



Rubber Mallet



Level



Safety Glasses



AIX (x4)  
Wood Shim (Provided)






## TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



AIX (x4)

**NO HARDWARE PROVIDED FOR THIS PAGE**

SEC 10



### SEC

#### 10.1

### DOOR ALIGNMENT

In some cases, the shed doors may not completely line up at the tops (fig. 1). When this happens, identify which side is higher and use a **Wooden Shim (AIX)** to slightly raise the back corner of the high side until doors line up (fig. 2). If doors need further adjustment, insert another shim under the front corner opposite of the first shim. If the doors still need further adjustment, stack additional shims (one at a time) alternating between the back and front shims. After doors are aligned, cut off any portion of wood shim that is still exposed. From inside the shed, drive a 1" nail through the floor into the shim to hold it in place. **Tighten all anchoring hardware now.**




Fig. 1





Fig. 2



**Note:** Shim should be placed at the corner, running directly under one wall.

## ***CLEANING & CARE***

Congratulations on your Lifetime® product purchase. By following the instructions below, your new Lifetime product should provide you with years of service and enjoyment.

### **Cleaning and Care**

The polyethylene panels are stain- and solvent-resistant. Most stains can be removed, using a mild soap and a soft-bristled brush. Abrasive cleaning materials may scratch the plastic and are not recommended. Repair scratches or rust spots on the metal by sanding the affected area lightly; using a rust preventative spray primer; and finally, spraying with a high-gloss spray enamel paint. Avoid placing a direct heat source on or near surfaces unless using a heat barrier.

## **LIFETIME OUTDOOR SHED EQUIPMENT**

### **10-YEAR LIMITED FACTORY WARRANTY**

**THE MANUFACTURER RESERVES THE RIGHT TO MAKE SUBSTITUTIONS TO WARRANTY CLAIMS IF PARTS ARE UNAVAILABLE OR OBSOLETE.**

1. Lifetime outdoor sheds are warranted to the original purchaser to be free from defects in material or workmanship for a period of ten years from the date of original retail purchase. The word “defects” is defined as imperfections that impair the use of the product. Defects resulting from misuse, abuse or negligence will void this warranty. This warranty does not cover defects due to improper installation, alteration or accident. This warranty does not cover damage caused by vandalism, rusting, “acts of nature” or any other event beyond the control of the manufacturer.
2. This warranty is nontransferable and is expressly limited to the repair or replacement of defective product. If the product is defective within the terms of this warranty, Lifetime Products, Inc. will repair or replace defective parts at no cost to the purchaser. Shipping charges to and from the factory or distribution center are not covered and are the responsibility of the purchaser. Labor charges and related expenses for removal, installation or replacement of the shed or its components are not covered under this warranty.
3. This warranty does not cover scratching or scuffing of the product that may result from normal usage. In addition, defects resulting from intentional damage, negligence, unreasonable use or hanging from the truss will void this warranty.
4. Liability for incidental or consequential damages is excluded to the extent permitted by law. While every attempt is made to embody the highest degree of safety in all equipment, freedom from injury cannot be guaranteed. The user assumes all risk of injury resulting from the use of this product. All merchandise is sold on this condition, and no representative of the company may waive or change this policy.
5. This product is not intended for institutional or commercial use; Lifetime Products, Inc. does not assume any liability for such use. Institutional or commercial use will void the warranty.
6. This warranty is expressly in lieu of all other warranties, expressed or implied, including warranties of merchantability or fitness for use to extent permitted by Federal and state law. Neither Lifetime Products, Inc., nor any representative assumes any other liability in connection with this product. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

#### **PLEASE INCLUDE YOUR DATED SALES RECEIPT AND PHOTOGRAPHS OF DAMAGED PARTS.**

REPORT PRODUCT DEFECTS IN WRITING TO:

Lifetime Products, Inc., PO Box 160010 Clearfield, UT 84016-0010  
or call 1-800-225-3865 M-F 7 a.m. to 5 p.m. MST.

#### **REGISTER YOUR PRODUCT FOR QUICKER CUSTOMER SERVICE.**

Visit [www.lifetime.com](http://www.lifetime.com) or call 1-800-225-3865 to register your product today.

#### **FOR INTERNATIONAL WARRANTY CLAIMS:**

All warranty claims must be accompanied by a sales receipt. Report all warranty claims in writing to your regional sales support representative. Please include your dated sales receipt and photographs of damaged parts.  
To Identify the representative for your region — Please visit: [www.lifetime.com/international](http://www.lifetime.com/international)



[www.lifetime.com](http://www.lifetime.com)

**ENHANCE YOUR LIFETIME® PURCHASE BY ADDING ACCESSORIES OR OTHER GREAT PRODUCTS**

---

*To purchase accessories or other Lifetime Products, visit us at:*

***[www.lifetime.com](http://www.lifetime.com)***

***Or call: 1-800-424-3865***

---

